

LANE COVE SECURITY



Playback

These instructions detail how to use a **local monitor and mouse** to playback recorded footage from your system.

1. **Right-click** anywhere on the *live view* screen.
2. Select **Playback** from the context menu.
3. Choose the desired **camera**, **date**, and **time range** for playback.
4. Click **Search** to load the recorded footage.
5. Use the playback controls:
 - **Play/Pause**
 - **Fast-forward**
 - **Drag the time bar** to jump to a specific point in time

Exporting Footage

These instructions detail how to export the required footage from your system to a local USB drive.

1. During playback, click the **scissors icon** to mark the *start* and *end* time of the desired footage.
2. Click the **Export** button.
3. **Insert a USB stick** into the NVR.
4. In the export window, select **USB** as the destination.
5. Choose the desired **export format**: MP4 (recommended for general use) or Hik Proprietary format (requires special player).
6. Click **Export** again to begin the export process.

Note: If you are having trouble with USB recognition, try a different USB drive, and double check that the file system is set to FAT32.